


Imported by Furniture Solutions (Aust) Pty Ltd New South Wales, Australia.
For any assistance with assembly or for missing parts please contact:
Place of purchase or Furniture Solutions on below
Customer Service (Australia) Phone-1300 794 188
Email- customerservice@furnituresolutions.com.au


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads













ALLOW TIME









PEOPLE REQUIRED

PARTS LIST



A	 M8X38mm	4PCS	D	 M8x35mm	2PCS	G	 6mm	1PC
B		2PCS	E	 M8x70mm	2PCS	H	 5mm	1PC
C	 M6X20mm	2PCS	F	 M6X20mm	4PCS	I	 4mm	1PC

1.Chair Base With Cushion	2.Backrest Cushion	3.Armrest Pads
		
4.Footstool Cushion	5.Lwoods For Footstool	6.Footstool Base
		

ASSEMBLY INSTRUCTIONS




Please prepare work area as instructed in page 2:

To assemble Footstool:

Identify required hardware before you start assembly. Note do not over tighten any bolts, tighten only till firm.

Take footstool base [6] & LWood [5] line up holes, then with bolt & washer (A) insert thru hole then by hand turn bolt (A) 2-3 times to seat thread correctly, repeat for second bolt (A), once both seated tighten with tool (G). Repeat for next LWood. Note ensure L Woods are facing same direction.

Next turn footstool cushion [4] upside down as shown in diagram, insert bracket [B] into LWood as shown in diagram. Line up slots on bracket [B] with hole in footstool cushion [4] place bolt & washers [C] into hole and by hand turn 2-3 times to seat bolt (C) into thread correctly. Repeat for other side. Once both bolts (C) are seated correctly, take tool [I] and tighten until firm. Footstool complete. Note slots in bracket [B] allow for some adjustment to keep L Woods square.




ASSEMBLY INSTRUCTIONS

To Assemble Chair, attach backrest [2]

Take chair base with cushion [1] place in upright position as shown in diagram, with the help of second person, bring backrest [2] to chair base [1].

Located at base of backrest & back of seat there are black metal tubes that have holes, you may have to peel back fabric covering to locate. While second person holds back rest level as depicted in diagram, so bolts [D] can be inserted and seated into thread provided, then by hand seat both bolts [D] to ensure not to cross thread. Once both seated correctly tighten with tool [G] tighten till you feel resistance, do not over tighten.

Please see diagram and remove black packaging from behind glide handle.




ASSEMBLY INSTRUCTIONS

To Assemble Chair, attach backrest [2]


Now attach upper section of back rest to back of black bracket as shown in diagram, again second person required to keep backrest square while fitting bolts [E]. By hand start bolt (E) thru hole in bracket into backrest [2] again you may have to peel back leather covering to locate threaded hole. Once both seated correctly take tool [G] and tighten bolts.

Note these bolts [E] are used as a pivot point for backrest movement and do not need to be tighten flat against metal.



To attach Armrest: Place armrest [3] as indicated in diagram, align holes in armrest [3] with holes on bracket. Using bolt [F] insert bolt thru hole in bracket and into armrest (3) then by hand seat bolt properly 2-3 turn, do not tighten until both bolts are fitted by hand. Once both seated use tool (F) to tighten. Repeat for other side.

ASSEMBLY COMPLETE



FEATURE'S AND OPERATING OF RECLINER


FEATURE:

Twin glide handle locking.

The locking mechanism is design for variable recline positions, so you can find the right spot for you to sit.


Please view diagrams below for operation of the glide handle system.

Reclining function




Recliner Position Control

Hold and Release:



Caution:

Avoid placing hand between lever and frame.



FEATURE'S AND OPERATING OF RECLINER

FEATURE:

Adjustable head rest.

Internal adjustable headrest for variable use.

Please view diagrams below for operation of the adjustable headrest.




To Adjust Headrest: Place both hands over shoulder as shown in diagram. Gently pull with both hands to desired position.



DO NOT PULL FROM SIDE: May cause damage to seams.



To return headrest back: push on both sides or use forearm to evenly move headrest back.



CAUTION


Always apply pressure to edge of Frame never in middle of headrest as may cause damage to filling.

FEATURE'S AND OPERATING OF RECLINER

FEATURE:

Swivel base.

Complete 360 degree turning circle.




FEATURE:


Adjustable tension on glide handle.

The glide handle can be customised to suit the individual.


Please follow step by step instructions below if you require to alter tension on glide handle



Take off plastic cover from handle.



To adjust tension on glide action. With 4mm Allen Key adjust clockwise to tighten grip and anti clockwise to loosen. Note do not over tighten as handle will not lock properly.



Put plastic cover back to handle bar.

CARE AND MAINTENANCE

Varieties of materials are used in construction of “Recliner” furniture range, Such as Stainless Steel; Chrome plated steel: Powder coated steel, Timber, Leather, PU synthetic fabric & a variety fabric. All will require some form of maintenance to extend the life of finishes and general appearance.

Please see below instruction unique to your chosen model.

Rhone Recliner Chair and footstool

Covering : Polyester knitted fabric

Base : Laminated timber

Polyester Fabric;

Vacuum regularly with a soft brush attachment or low suction to remove dust and grit.

Treat spills and stains immediately.

Spot cleaning only use proprietary cleaning agents, follow instruction the instructions provided.

Do not rub excessively, do not use solvent based cleaners, do not use dishwashing or laundry detergent. Allow to dry before use.

Periodic Fabric Cleaning;

Recommend professional cleaning with an hot water extraction machine, to remove grim build up from every day use.

Fabric Protection;

Please ensure you follow all instructions on product provided, we recommend the use of water based fabric protection treatment.

Laminated Timber Base and Swivel Action;

Please remove dust and grit on exposed timber as required.

Every 3-4months lay chair over on it's back please wipe and or vacuum action inside chair to remove excess dust and fluff, pay special attention to swivel action at base of chair, ensure all metal components are clean and free of impediments.

SAFETY WARNINGS AND ADVICE

Notices and Advice

Please be advised that products are limited in design for residential use only and are not suitable for commercial use.

Please be advised that materials used in your furniture are not impervious to neglect, acts of god, abuse, alcohol spills, improper use of chemicals such as bleach or any solvent based products.

Please be advised that heat sources such as direct sunlight, log fires, heaters and air conditioners can have adverse affects on your furniture.

Please be advised that fitting, bolts, nuts and or screws should be checked periodically to ensure they have not loosened over time. Remember do not overtighten.

DO NOT

- Place in direct sunlight.
- Place in close proximity to open flame or heaters.
- Place in direct line of air conditioning ducting.
- Leave spills or food on sofa clean off immediately
- Pull loose thread, cut them instead.
- Sit or lean on arms
- Stand on chair

Safety warnings

- DO NOT:
- drop, drag always with the help of another person lift and place, to avoid damage to floor surface & base of recliner chair.
- Sit on arms or back when upright, this could damage internal mechanism.
- Fold mechanism with linen or cushions on sofa.
- Pull loose thread, cut them instead.
- Jump, flop or stand on sofa.
- Always release both glide handles before you attempt to move into upright position.
- Ensure swivel mechanism on chair base is clear of loose threads, long carpet fibre's or simular items

WARRANTY DETAIL

2 Year Warranty

A two (2) year warranty applies to product against any defects associated with faulty workmanship for a period of (2) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear including fading, creasing of covering, aging of foam and fibre filling IE Height reduce over time, stains from spills, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty is based on normal household use and not for commercial use. Warranty only extends to original purchaser and is not transferable, except when given as a gift.

Notice:

While every effort is made to use quality materials our products are limited in design for domestic use only & are not suitable for commercial use.
Care should be taken not to place product near heat sources.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure long life of use for product. Instruction manuals are designed with the nature of materials used in construction of the product.

*Proper use of item only what it is designed to do

*Regular maintenance and cleaning

In areas of high content of salt air, pollution & moisture require more frequent cleaning.

Claim management:

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details on page one. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. If missing parts please refer to assembly instructions for identification of said part and contact either of the above.

“Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure”.