
= Furniture Solutions =



INSTRUCTION MANUAL TOULON RECLINER CHAIR ITEM CODE: 17TOUHE



Imported by Furniture Solutions (Aust) Pty Ltd New South Wales, Australia. For any assistance with assembly or for missing parts please contact: Place of purchase or Furniture Solutions on below Customer Service (Australia) Phone-1300 794 188 Email- customerservice@furnituresolutions.com.au

1


PRE-ASSEMBLY PREPARATION

Before you start:


- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use

2


- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads







PEOPLE REQUIRED




ASSEMBLY INSTRUCTIONS

Please prepare work area as instructed in page 2:

To attach armrest:

Please arrange chair base with cushion [1] as displayed in diagram below. Locate threaded holes inside the extended arm support. Take angled plate [A] and aline holes in angled plate with threaded holes as indicated above. Note wording on angled plate please face wording towards seat. Take bolt [B] and by hand insert thru hole into thread and turn 2-3 times to seat thread correctly, repeat for other bolt. Once both seated correctly take tool provided [D] and tighten both bolts. Repeat for other arm support section. Then take armrest pad [3], take note of the diagram for correct direction place armrest pad. Next aline holes in angled plate with threaded holes under armrest pad. Then by hand insert bolt [C] turn 2-3 times to seat thread correctly, do not tighten yet. Repeat for other bolt. Once both bolt are seated correctly, take tool [D] and tighten. Repeat for other armrest pad. Move to next page




4

ASSEMBLY INSTRUCTIONS

To attach backrest [2]

Please review diagram below and locate the black tube fittings shown, note the tube section in the chair base with cushion has a screw pre-fitted, please locate this before you start assembly.

With the help of a second person in unison aline & slide the tube in backrest [2] into tube in chair base with seat. Note both need to inserted at the same time, you may need to push up material to get a clear view. Once insert ensure both sides are level and backrest has been pushed down into tube. Once your happy tubes are seated correct take tool [D] and tighten bolt grub screws until firm. Not do not overtighten. Assembly complete move to next page.





Operating recliner footrest:


To raise footrest.

Place both hands on armrest pads as indicated in diagram. While leaning back into chair push on backrest from your hands up to shoulders, while not having any tension in your legs.

To Lower footrest.

Please have backrest in fully upright position, then simply lean forward and use lower muscles in your legs to push down footrest.

Caution only operate footrest when backrest is in fully upright position.



7

Do not raise footrest from this position.

Do not attempt to stow footrest from this position.


Operating recliner backrest:

To lower backrest.

Please locate on right hand side of seat a looped strap this is used to release pin inside mechanism of recliner action. Pull on loop and lean back on backrest. Release loop when you have desired angle on backrest, pin will automatically find a locking position.

To raise backrest.


Simply pull on loop again, lean forward hold onto to loop till chair is back in full upright position then release. Chair will lock in upright position.



FEATURE:


Swivel base.

Complete 360 degree turning circle.






To raise the footrest, grasp both armrests and push forward while leaning back in the recliner.



Solution To return the recliner to an upright position, pull the strap loop and sit up.



☑ To fully recline, pull the strap loop and lean backward.



To stow the footrest, push downward with your lower legs while seated.

9

FEATURE:

Adjustable head rest.

Internal adjustable headrest for variable use.

Please view diagrams below for operation of the adjustable headrest.




To Adjust Headrest: Place both hands over shoulder as shown in diagram. Gently pull with both hands to desired position.



DO NOT PULL FROM SIDE: May cause damage to seams.



To return headrest back: push on both sides or use forearm to evenly move headrest back.



CAUTION

Always apply pressure to edge of Frame never in middle of headrest as may cause damage to filling.

10 17TOUHE

CARE AND MAINTENANCE

Varieties of materials are used in construction of "Recliner" furniture range, Such as Stainless Steel; Chrome plated steel: Powder coated steel, Timber, Leather, PU synthetic fabric & a variety fabric. All will require some form of maintenance to extend the life of finishes and general appearance.

Please see below instruction unique to your chosen model.

Toulon Recliner Chair

Covering: Polyester knitted fabric

Base: Laminated timber

Polyester Fabric;

Vacuum regularly with a soft brush attachment or low suction to remove dust and grit. Treat spills and stains immediately.

Spot cleaning only use proprietary cleaning agents, follow instruction the instructions provided. Do not rub excessively, do not use solvent based cleaners, do not use dishwashing or laundry detergent. Allow to dry before use.

Periodic Fabric Cleaning;

Recommend professional cleaning with an hot water extraction machine, to remove grim build up from every day use.

Fabric Protection;

Please ensure you follow all instructions on product provided, we recommend the use of water based fabric protection treatment.

Laminated Timber Base and Swivel Action;

Please remove dust and grit on exposed timber as required.

Every 3-4months lay chair over on it's back please wipe and or vacuum action inside chair to remove excess dust and fluff, pay special attention to swivel action at base of chair, ensure all metal components are clean and free of impediments.

11

SAFETY WARNINGS AND ADVICE

Notices and Advice

Please be advised that products are limited in design for residential use only and are not suitable for commercial use.

Please be advised that materials used in your furniture are not impervious to neglect, acts of god, abuse, alcohol spills, improper use of chemicals such as bleach or any solvent based products.

Please be advised that heat sources such as direct sunlight, log fires, heaters and air conditioners can have adverse affects on your furniture.

Please be advised that fitting, bolts, nuts and or screws should be checked periodically to ensure they have not loosened over time. Remember do not overtighten.

DO NOT

- · Place in direct sunlight.
- Place in close proximity to open flame or heaters.
- Place in direct line of air conditioning ducting.
- Leave spills or food on sofa clean off immediately
- Pull loose thread, cut them instead.
- Sit or lean on arms
- Stand on chair

Safety warnings

- DO NOT:
- drop, drag always with the help of another person lift and place, to avoid damage to floor surface & base of recliner chair.
- Sit on arms or back when upright, this could damage internal mechanism.
- Fold mechanism with linen or cushions on sofa.
- Pull loose thread, cut them instead.
- Jump, flop or stand on sofa.
- Always release both glide handles before you attempt to move into upright position.
- Ensure swivel mechanism on chair base is clear of loose threads, long carpet fibre's or simular items

12

WARRANTY DETAIL

2 Year Warranty

A two (2) year warranty applies to product against any defects associated with faulty workmanship for a period of (2) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear including fading, creasing of covering, aging of foam and fibre filling IE Height reduce over time, stains from spills, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty is based on normal household use and not for commercial use. Warranty only extends to original purchaser and is not transferable, except when given as a gift.

Notice:

While every effort is made to use quality materials our products are limited in design for domestic use only & are not suitable for commercial use.

Care should be taken not to place product near heat sources.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure long life of use for product. Instruction manuals are designed with the nature of materials used in construction of the product.

- *Proper use of item only what it is designed to do
- *Regular maintenance and cleaning

In areas of high content of salt air, pollution & moisture require more frequent cleaning.

Claim management:

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details on page one. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. If missing parts please refer to assembly instructions for identification of said part and contact either of the above.

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure".

13 17TOUHE