











ASSEMBLY INSTRUCTION MODEL: KNOX CHAISE

Parts List

A		Sofa
B		U Leg X 2
C		Scatter Cushion x 1
D		Bolt x 8
E		Allen Key
F		Washer x 8




Step 1: With help of another person place sofa section upside down on a soft clean surface.

Step 2: Remove item from zipped section as shown in figure 1.

Step 3: Fitting of LEGS Take U leg (B) place over holes in sofa base, then by hand insert bolt (D) with washer (F) into leg frame thru to sofa seat bolt into thread 2-3 turns repeat for all 4 bolts before using Allen key (E) to tighten. Repeat for other leg

Ready for Use





OPERATING INSTRUCTION MODEL: KNOX CHAISE

Click Clack Sofa-Bed operates on a 3-stage ratchets system.

Starting from flat position

Step 1: Lift backrest till you hear a click that will hold at mid angle, to increase to full upright position pull backrest forward again till you hear a click that will hold at full upright position.

Starting from full upright position

Step 2: Pull back towards front till you hear a clack that will release the lock on ratchets system, once released with your assistance lower back till flat. Note once lock is released back will only go to flat position if you require it to go to mid angle position you will need to start from flat position as instructed above.

Warning do not operate when in use IE: person laying a sofa, loose blankets & or Cushions that could get caught in mechanism.

Note never drag sofa always lift with help of another person.

