


INSTRUCTION MANUAL

ONYX ROUND BALCONY TABLE

ITEM CODE: 17ONY02B



Imported by Furniture Solutions (Aust) Pty Ltd New South Wales, Australia.

For any assistance with assembly or for missing parts please contact:

Place of purchase or Furniture Solutions on below


Customer Service (Australia) Phone-1300 794 188

Email- customerservice@furnituresolutions.com.au


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads





ALLOW TIME



PEOPLE REQUIRED

COMPONENT & HARDWARE LIST



	PART	CODE
1	TABLE TOP x 1	P.70406.TT
2	Up Leg	P.70406.UL
3	Down Leg	P.70406.DL
4	X Brace	P.70406.XB

Fittings

A	 Ø6 x 45	x12
B	 Ø6 x 25	x 4
C	 Ø4 x 60	x 1
D	 Ø4 x 60	x 2

ASSEMBLY INSTRUCTIONS

Leg System:


Prepare product as per page 2:

First Step is assembly of leg frame Diagram indicates how they slide together.

With the help of another person to hold pieces in position. Take the up leg [2] and hold vertical, then slide in the down leg as per diagram. Have second person hold the leg in place and square.

Move to step 2.

Step 1:



ASSEMBLY INSTRUCTIONS

Leg System:


Prepare product as per page 2:

Step 2 is to fit X brace [4] to leg system. Not X brace does have 2 sides, flat side and a side that has corner rounded off . While second person hold legs square, place the X brace with round corner facing down and aline the holes with both leg and brace, take bolt washer [A] and by hand insert bolt into thread, turn 2-3 turns to ensure thread has gripped, test by lightly pulling back on bolt. Do Not Tighten, fit the balance of bolt in same manner until all eight (8) bolts are fitted.

To help ensure to finished product is square I ask you at this stage to attach fitting [C]. You will need to turn leg system over. Note at the junction of leg there are four (4) holes with thread one (1) in each leg, lay fitting [C] over holes and aline, next take bolt and washer [B] and by hand turn 2-3 times to ensure thread has gripped, fit all four bolts. DO NOT TIGHTEN. Now flip back over and follow instruction.

When all of bolt [A] are fitted correctly take tool [D] and tighten all bolts. Unsure not to over tighten as this may cause damage to fittings inside timber. Move to step 3

Step 2:



ASSEMBLY INSTRUCTIONS

Fit Leg System to Table Top

Prepare product as per page 2:


Please ensure you place table top on a soft flat surface IE: Blanket on the ground, also lift table top into position do not roll. Place table top [1] upside down and locate the four (4) threaded holes, take leg system and line up the holes, Then by hand insert bolt and washer [A], ensure to thread correctly turn 2-3 times. To test if gripped pull back lightly. **DO NOT TIGHTEN YET**, please fit the other 3 bolts with same method. Once all 4 bolts are seated correctly, take tool [D] and tighten, not do not overtighten. Note you will need to tighten the bolts [B] at junction of legs.

Assembly is now complete.

With the help of a second person lift completed table into the and roll over until feet are level with ground, now gently lower.

Important that you never drag table always lift to move.

Please see care instruction for timber preparation before putting into use.



CARE AND MAINTENANCE

Varieties of materials are used in construction of “Outdoor” furniture ranges.

All will require some form of maintenance to extend the life of finishes and general appearance.

Please see below instruction unique to your chosen product.

Onyx Dining Range Construction;

Table Top: Fibre Stone

Base: Acacia Timber

Fibre Stone:

Poly + sand + stone powder mixed and poured into a matrix or moulding frame, this produces a panel of required size of 5mm thickness. Then a layer of fiberglass is applied to back of panel to add strength and rigidity and during the assembly process a further support system is added a steel frame to avoid flex. Once this is added another panel is added to seal all panels into a box. Finishing is apply to surface sanding and a final coat of clear paint is sprayed on.

Care Instruction;

Please keep dust free, avoid leaving vegetation on surface as leaves and sap can leave stains that can not be removed. Avoid leaving spills on surface as orange juice & alcohol are acidic and will damage surface coating if left unattended for any length of time.

Regular cleaning please use a soft bristle dust pan brush or a soft clean cloth, using a hose is permissible but not at high pressure, please pat dry as the trace minerals in water may leave a mark once water has evaporated (Do Not Use Bore Water).

Included in packaging is a small can of wax, note this is for cleaning of grime build up.

Using a soft clean cloth you apply the wax in a circular motion to affected area, with this action the wax then picks up the grime and retains the grime within its self, then with a soft clean cloth remove the wax taking the grime with it. Repeat if necessary. Note may not clean up all especially any dye based grime and or chemicals.

Base: Acacia Timber

Natural finish on timber will require treatment to reduce swelling of timber from moisture intake. Please apply a clear coating of decking oil (solvent based) once you have assembled and follow advice from hardware specialist or from the can for future maintenance.

Wood is a living material and over time minor cracks and colour changes will occur. This is a natural reaction for timber exposed to the elements. Oiling is the key to reduce effects.

CARE AND MAINTENANCE

Definition of Regular Cleaning;

Numerous factors can influence the time frame for cleaning, depending area you live in, the weather, positioning of the product (fully protected, partial protection, fully exposed to the elements). You will need to monitor yourself to establish the cleaning requirement for your unique situation.

Areas with high salt content and or pollution will require the most frequent cleaning. To reduce some maintenance you should buy and use an outdoor cover to protect your furniture from the elements when not in use.

.

SAFETY WARNINGS AND ADVICE

Notices and Advice

Please be advised that products are limited in design for residential use only and are not suitable for commercial use.

Please be advised that materials used in your furniture are not impervious to neglect, acts of god, abuse, alcohol spills, improper use of chemicals such as bleach or any solvent based products.

Please be advised that heat sources such as barbeques, open fires, temporary/mobile/overhead heaters, poorly insulated candle holders, hot pots, pans, hot serving dishes can have adverse affects on your furniture.

Please be advised that fitting, bolts, nuts and or screws should be checked periodically to ensure they have not loosened over time. Remember do not overtighten.

Please be advised coverings are not animal proof. Claws can scratch covering & saliva is acidic and can damage finish.

DO NOT

- Place in close proximity to open flame or heaters.
- Leave spills or food, clean off immediately
- Pull loose thread, cut them instead.
- Sit or lean on arms
- Stand on chair or bench's
- Stand on table tops
- Place heavy objects on table tops
- Place objects such as pot plants as a display piece on tables recommend weight restriction for table top is 60kg across the table.

Safety warnings

- DO NOT:
- drop, drag always move furniture with the help of another person lift and place only
- Over load bench seats recommended weight evenly distributed is 360kg IE: 3 people 120kg each; 4 people 90kg each.
- Tables, chairs & bench's are designed for seating, not work bench's.
- Allow child to play under table

Warranty Detail:**1 Year Warranty**

A one (1) year warranty applies to product against any defect associated with faulty workmanship for a period of (1) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear, stains from spills/vegetation, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty only extends to original purchaser and is not transferable, except when given as a gift. Goods are limited in design for domestic use only, and are not suitable for commercial use.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure a long life of use for product.

*Proper use of item, only what it is designed to do. Designed for dining, not suitable for use as a workbench, substitute ladder or dance floor.

*Regular maintenance and cleaning: Please consult your Instruction manual included in packaging for advice of cleaning

*Protecting product from the harsh environment: Pollution, excessive moisture & heat.

To extend the life of your outdoor furniture we recommend the following furniture covers must/should be used on furniture which is used in areas not protected from elements.

Caution should be used when using oils, lotions & other chemicals such as chlorine not to spill on furniture.

Instruction Manual – Have been written to suit individual materials used in construction, please retain for future use for duty of care, assembly, parts & component sizing.

Claim management:

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details below. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. If missing parts please refer to assembly instructions for identification of said part and contact either of the above.

“Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure”.