Furniture Solutions = VEGA BARSTOOL

Made in China Imported by Furniture Solutions (Aust) Pty Ltd 10-16 Daisy St, Revesby, NSW. 2212

Item# 18VEGBSX2.AB Height: 762mm Seat: 406mm Round Stain: Aged Barley

Your furniture purchase is an investment.

Here are a few tips to maximize the lifetime of your furniture with a minimum, amount of effort.

Properly caring for your furniture can help ensure that it looks great year after year.



Wood Furniture Maintenance:

Note no added polishing is required.

Always dust, wipe, and clean with the grain of the wood. Dust with a soft clean cloth.

Dust will scratch the furniture surface if not removed properly! If a polished surface becomes foggy.

Rub it with a cloth dipped in a solution of one tablespoon vinegar to one liter of water. Rub softly with the grain until the surface is completely dry.

Soap and water are not advisable for wood surface.

Water can penetrate the finish and raise the grain on wood, causing damage.

Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface.

Iron Work Maintenance:

Keep dust free: Bolts and screws must be checked and re-tightened as necessary or minimum very 6 months. Paint chips should be touched up as they occur. When bare metal is exposed to environment, metal will first oxidize and next stage will be rust, causing structural integrity to be compromised.

The Enemies of Wood:

Moisture is wood's worst enemy.

Liquid spills should be gently wipe up immediately.

Coasters should be used under all beverages.

Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain.

Put a strip of felt or leather under accessories that have rubber or vinyl.

Heat creates a chemical change in the furniture's finish, which result in a white spot. Use protective pads under hot dishes, appliances, etc.


Sunlight's ultraviolet rays can damage the finish of furniture.

Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

The Enemies Iron Work:

All iron or steel products are painted to protect metal from the elements.

Do not immerse in water. Liquid spills should cleaned off immediately. Alcohol, fruit juice etc are acidic and can cause paint finish to change colour. When cleaning please use only Ph neutral products.



PRE-ASSEMBLY PREPARATION

Avoid use of powered/battery drills.


Improper use of drills can irreversible damage fittings.

Before you start:

- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. **Ensure to check all components for any damage before assembly**. Please report any damage found to below, if possible forward images of component to below
- 5. Always read the assembly instructions carefully before beginning assembly.
- 6. Keep all hardware parts and packaging out of reach of small children.
- 7. Do not over tighten the screws and bolts as this may damage the threads



ALLOW TIME



PEOPLE REQUIRED

For any assistance with assembly or for missing parts Please contact:


Place of purchase or Furniture Solutions. Customer Service (Australia) Phone-1300 794 188 Email- customerservice@furnituresolutions.com.au

Vega Barstool Hardware and Component List Hardware List:Item #PVG420BS-AH

A	0	Spring Washer 6mm	12PCS
В		Flat Washer 6mm x 13mm	12PCS
C		Bolt 6mm x 16mm	12PCS
D		Tool 4mm	1PC

Componet List

Please note factory have pre-assembled seat frame, swivel plate and seat bottom frame. Factory has also pre-fitted the plastic plug in base of leg.



Assembly Instructions

Prepare as instructed on page 2: Follow steps do not move ahead

Step 1: Fit 3 legs to base of seat as shown below, note leg has a threaded hole inside of tube, this faces into the middle of stool seat.


STEP#1

Take bolt (C) add spring washer (A) also add flat washer (B). Ensure to place washers in correct order.

Insert bolt with washer into base of leg and into thread in base of seat, bolt needs be seated properly by hand turn bolt 2-3 times, test it has gripped by gently pulling back on bolt.

Please fit second bolt in same manner. Then hand tighten both bolts until they feel firm.

Repeat for the other two legs Move to Step#2



Step 2: Fit Ring as indicated in diagram, ensure the tongue with hole is facing up the leg.


Take bolt (C) add spring washer (A) also add flat washer (B). Ensure to place washers in correct order.

Insert bolt with washer into base of leg and into thread in base of seat, bolt needs be seated properly by hand turn bolt 2-3 times, test it has gripped by gently pulling back on bolt.

Please fit other two (2) bolts in same manner. Then hand tighten both bolts until they feel firm.

Move to Step#3

STEP#2



Assembly Instructions

Step 3: Fit last Leg as indicated in diagram. Please follow same method as previously shown. remember to only do bolts up finger tight.

Once you have fitted by hand all bolts, you need to ensure that the stool when finished is square/level.


Suggest you turn stool over gently onto it's feet, ensure surface is level.

Then by eye line up ring and base of seat so they are square with each other, then take tool (D) and start to tighten bolts that go into ring.

Once all bolts are tight gently turn stool back over and proceed to tighten all other bolts. Assembly now complete

Move to Step#4

STEP#3



Step 4: Once assembly complete, Turn barstool over on it's feet. Take a seat and test swivel action.

Trouble shooting.

If you find barstool is not level please check list below

- Ensure area is level. Test by moving stool to a different location and or turn stool around.
- Ensure all legs have plastic plug fitted. If missing contact your reseller or Furniture Solution direct
- Possible cause could be incorrect assembly.
 Please take tool provided and loosen bolts in ring section, put some weight on top of stool and again by eye check level, then re-tighten bolts.

Test again the first two (2) suggestion. should now be level.

STEP#4



If level problem still remains please contact your reseller or Furniture Solution Direct. Please ensure that you follow above trouble shooting list before contacting reseller or Furniture Solution as incorrect assembly is not covered under warranty and fees may be applied.

WARRANTY DETAIL

1 Year Warranty

A one (1) year warranty applies to product against any defect associated with faulty workmanship for a period of (1) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear, stains from spills/vegetation, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty only extends to original purchaser and is not transferable, except when given as a gift.

Notice:

While every effort is made to use quality materials our products are limited in design for domestic use only & are not suitable for commercial use.

Care should be taken not to place product near heat sources.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure long life of use for product.

Instruction manuals are designed with the nature of materials used in construction of the

Instruction manuals are designed with the nature of materials used in construction of the product.

- *Proper use of item only what it is designed to do
- *Regular maintenance and cleaning

In areas of high content of salt air, pollution & moisture require more frequent cleaning. **Claim management:**

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details below. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. Note costs associated with the warranty claim, other than the rectification of the fault, are the responsibility of the claimant, except those required under the Australian Consumer Law. The benefits provided to the consumer by the warranty are in addition to other rights and remedies available to the consumer under the law.

If missing parts please refer to assembly instructions for identification of said part and contact either of the above.

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure".