= Furniture Solutions =

Made in China Imported by Furniture Solutions (Aust) Pty Ltd 10-16 Daisy St, Revesby, NSW. 2212**Y**

Zica Dining Table

Item# 18ZIC05AB Size:114cm Round Stain: Aged Barley



Your furniture purchase is an investment.

Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

Always dust, wipe, and clean with the grain of the wood. Dust with a soft clean cloth. Dust will scratch the furniture surface if not removed properly.

If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one litre of water. Rub softly with the grain until the surface is completely dry.

Soap and water are not advisable for wood surface. Water can penetrate the finish and raise the grain on wood, causing damage.

The Enemies of Wood:

Moisture is wood's worst enemy.

Liquid spills should be gently wipe up immediately. Coasters should be used under all beverages. Do not allow rubber or vinyl materials to lie on the furniture.

Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl. Heat creates a chemical change in the furniture's finish, which result in a white spot.

Use protective pads under hot dishes, appliances, etc. Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

Iron Work Maintenance:

Keep dust free; Bolts and screws must be checked and re-tightened as necessary or minimum very 6 months. Paint chips should be touched up as they occur. When bare metal is exposed to environment, metal will first oxidize and next stage will be rust, causing structural integrity to be compromised.

The Enemies Iron Work:

All iron or steel products are painted to protect metal from the elements.

Do not immerse in water. Liquid spills should cleaned off immediately. Alcohol, fruit juice etc are acidic and can cause paint finish to change colour. When cleaning please use only Ph neutral products.




PRE-ASSEMBLY PREPARATION

Avoid use of powered/battery drills.

Improper use of drills can irreversible damage fittings.

Before you start:

- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. **Ensure to check all components for any damage before assembly**. Please report any damage found to below, if possible forward images of component to below
- 5. Always read the assembly instructions carefully before beginning assembly.
- 6. Keep all hardware parts and packaging out of reach of small children.
- 7. Do not over tighten the screws and bolts as this may damage the threads



Important Advice:


Never place hot or cold items on surface without proper insulation. Always use place mats and drink coasters. Always clean up spills immediatly. Standing or sitting on table can cause harm to yourself as well as your furniture. Never drag table always lift to move, a second person will be required.

For any assistance with assembly or for missing parts Please contact: Place of purchase or Furniture Solutions. Customer Service (Australia) Phone-1300 794 188 Email- customerservice@furnituresolutions.com.au

Hardware List Zica DiningTable

А	Garana and a second	1PC	6mm X 40mm
В	S ammen	8PCS	6mm X 18mm
С	0	9PCS	ф 6.5mm
D		9PCS	Φ 6.5mm * Φ 19
Е		1PC	4X4mm

Component List



Assembly Instructions


* Do not tighten screws & bolts until the entire item is completely assembled.

STEP1

Please arrange table top as shown in diagram. Ensure the surface is level, clean and soft. Suggest a clean blanket or similar.

Please identify the top leg.
At the junction of the two legs one will have a hole all the way thru and other will have threading and block end.
Top leg is threaded model.

As shown in diagram Aline hole in top leg with threaded holes in table top, then take bolt [B] add spring washer [C] also add flat washer [D]. Insert thru hole as shown, then by hand seat thread correctly, turn 2-3 times and check bolt has gripped and is square. Repeat for other 3 bolts. You may at this stage take up the slack and tighten bolts until they are finger tight only. Move 2 Step 2.



STEP2


Next take bottom leg and link the two junctions as shown.

Take bolt [A] add spring washer [C] then add flat washer [D]. Insert bolt into hole at junction, ensure to seat thread correctly by turn bolt by hand 2-3 times. Check bolt has gripped.

Next Aline the holes in bottom leg as in step one and proceed to add bolts and washer as previously instructed.

Now all bolts are fitted correctly, do a visual check all pieces are square and aliened properly take tool provided [E] and start to tighten bolts. Please start with the bolt at junction of legs. Note do not over tighten as you may inadvertently cause damage to fittings.

Now with the help of a second person lift table into the air and rotate mid air until you can place table on all four feet at the same time.



SAFETY WARNINGS AND ADVICE

Notices and Advice

Please be advised that materials used in your furniture are not impervious to neglect, acts of god, abuse, alcohol spills, improper use of chemicals such as bleach or any solvent based products

Please be advised that heat sources such as direct sunlight, log fires, heaters and air conditioners can have adverse affects on your furniture.

Please be advised that fitting, bolts, nuts and or screws should be checked periodically to ensure they have not loosened over time. Remember do not overtighten.

Please be advised that products are limited in design for residential use only and are not suitable for commercial use.

DO NOT

- · Place in direct sunlight.
- Place in close proximity to open flame or heaters.
- Place in direct line of air conditioning ducting.

Safety warnings

- DO NOT:
- drop, drag or strike table surface
- sit or stand upon the table surfaces
- place heavy objects on glass
- place very hot or cold items on the table surface unless adequately thick table mats are used to prevent such items coming in contact with the surface
- scratch the surface or using as a chopping surface
- · allow children to play under tables
- · Never drag table always move by lifting
- Clean only as per instructions on previous page. Do not use washing powders or any other substances containing abrasives that may potentially scratch the surface

CHAIRS AND STOOLS

- Do not:
- Use chair/stool as a ladder
- Climb on the chair/stool
- Stand on the foot-rest of the chair, as this could lead to the stool becoming unbalanced and overturning

WARRANTY DETAIL

1 Year Warranty

A one (1) year warranty applies to product against any defect associated with faulty workmanship for a period of (1) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear, stains from spills/vegetation, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty only extends to original purchaser and is not transferable, except when given as a gift.

Notice:

While every effort is made to use quality materials our products are limited in design for domestic use only & are not suitable for commercial use.

Care should be taken not to place product near heat sources.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure long life of use for product. Instruction manuals are designed with the nature of materials used in construction of the product.

- *Proper use of item only what it is designed to do
- *Regular maintenance and cleaning

In areas of high content of salt air, pollution and moisture more frequent cleaning is required.

Claim management:

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details below. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. If missing parts please refer to assembly instructions for identification of said part and contact either of the above. Costs associated with the warranty claim, other than the rectification of the fault, are the responsibility of the claimant.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The benefits provided to the consumer by the warranty are in addition to other rights and remedies available to the consumer under the law.