



= Furniture Solutions =

CRISTA EXTENSION DINING TABLE




Avoid injury
2 people are required
to assemble this table


Ax1



Bx1



Cx1




Dx4



M8x 15mm

Ex8




M10x 20mm

Fx8




∅18x∅10x2mm

Gx1




5mm

Hx1




8mm

STEP 1




STEP 2



= Furniture Solutions = CRISTA EXTENSION DINING TABLE

STEP 3



NOTE: THE EXTENSION TABLE TOP IS LOCKED CLOSED DURING TRANSPORT TO PREVENT DAMAGE. UNLOCK BY RELEASING CLIPS ON EXTENSION TRACKS AS SHOWN. CLIPS ARE LOCATED UNDER THE TABLE TOP ON BOTH SIDES.

CARE AND MAINTENANCE

Glass Care Instruction

The glass used on this product is tempered for your safety.

Please refer to safety warning and advice section for use.

Remove liquids or other spills immediately.

Regularly wipe over with a soft clean cloth, ensuring sharp and abrasive material is removed prior.

Lightly dampen cloth with clean water if required.

Proprietary glass cleaning products can be used but surrounding metal or powdercoated metal surfaces must be wiped over with clean water to remove glass cleaner residual to avoid damage.

Lacquer and Paint Surfaces Care Instruction

Remove liquids and other spills immediately.

Do not use abrasives or chemical cleaners.

Do not rub hard or excessively.

Regularly wipe over with a soft clean cloth, preferably microfibre, ensuring abrasive or sharp material has been removed prior.

Dampen the cloth with clean water to remove light soiling that cannot be dusted off.

Proprietary cleaners that are pH neutral and non-abrasive or chemically aggressive can be used to remove grease and grime. Seek professional advice if you are not sure of cleaning agent suitability.

Use of polishing products is not recommended.

Powdercoated and Stainless Steel Care Instructions

Remove liquids and other spills immediately.

Do not use abrasives or chemical cleaners.

Do not rub hard or excessively.

Regularly wipe over with a soft clean cloth, preferably microfibre, ensuring abrasive or sharp material has been removed prior.

Dampen the cloth with clean water to remove light soiling that cannot be dusted off.

General Care Instructions

Every 6 months all bolts and screws should be checked and re-tighten as required.

Caution: Do not overtighten.

Regularly check all visible metal components such as legs or glass top support rails for scratches or dents and touch up with suitable colour paint. Exposed metal will oxidise (rust) unless touched up, particularly in seaside locations.

Stainless steel can show signs of surface oxidization. Wipe over with a soft cloth to remove and lightly spray with protective oil if necessary.

Do Not:

- Expose to direct sunlight, intensive heat, and weather or soak unnecessarily. Always avoid excessive hard rubbing
- Use saddle soap, detergents, solvents, abrasives, unidentified cleaners, or any products containing silicon or solvents

SAFETY WARNINGS AND ADVICE

Notices and Advice

Please be advised that materials used in your furniture are not impervious to neglect, acts of god, abuse, alcohol spills, improper use of chemicals such as bleach or any solvent based products.

Please be advised that heat sources such as direct sunlight, log fires, heaters and air conditioners can have adverse affects on your furniture.

Please be advised that fitting, bolts, nuts and or screws should be checked periodically to ensure they have not loosened over time. Remember do not overtighten.

Please be advised that products are limited in design for residential use only and are not suitable for commercial use.

DO NOT

- place in direct sunlight.
- place in close proximity to open flame or heaters.
- place in direct line of air conditioning ducting.

Safety warnings

DO NOT:

- drop, drag or strike table surface
- sit or stand upon the table surfaces
- place heavy objects on table top
- place very hot or cold items on the table surface unless adequately thick table mats are used to prevent such items coming in contact with the surface
- scratch the surface or using as a chopping surface
- allow children to play under tables
- Never drag table always move by lifting
- Clean only as per instructions on previous page. Do not use washing powders or any other substances containing abrasives that may potentially scratch the surface

Chairs and Stools

Do not:

- use chair/stool as a ladder
- climb on the chair/stool
- stand on the foot-rest of the chair, as this could lead to the stool becoming unbalanced and overturning
- drag chair always lift to move

WARRANTY DETAIL

1 Year Warranty

A one (1) year warranty applies to product against any defect associated with faulty workmanship for a period of (1) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear, stains from spills/vegetation, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty only extends to original purchaser and is not transferable, except when given as a gift.

Notice:

While every effort is made to use quality materials our products are limited in design for domestic use only & are not suitable for commercial use.

Care should be taken not to place product near heat sources.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure long life of use for product. Instruction manuals are designed with the nature of materials used in construction of the product.

*Proper use of item only what it is designed to do

*Regular maintenance and cleaning

In areas with high content of salt air, pollution & moisture require more frequent cleaning.

Claim management:

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details below. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. If missing parts please refer to assembly instructions for identification of said part and contact either of the above.

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure".



Made In China

Distributed in Australia & New Zealand by

Furniture Solutions (Aust) Pty Ltd

10-16 Daisy St,

Revesby, NSW. 2212

www.furnitureolutions.com.au

Email: customerservice@furnitureolutions.com.au

Customer Service (Australia) - PH: 1300 794 188