

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Imported by Furniture Solutions (Aust) Pty Ltd New South Wales, Australia.

For any assistance with assembly or for missing parts please contact:

Place of purchase or Furniture Solutions on below

Customer Service (Australia) Phone-1300 794 188

Email-customer-service@furniture-solutions.com.au


PRE-ASSEMBLY PREPARATION

Avoid use of powered/battery drills.


Improper use of drills can irreversible damage fittings.

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. **Ensure to check all components for any damage before assembly.** Please report any damage found to below, if possible forward images of component to below
5. **Always read the assembly instructions carefully before beginning assembly.**
6. Keep all hardware parts and packaging out of reach of small children.
7. Do not over tighten the screws and bolts as this may damage the threads



ALLOW TIME



PEOPLE REQUIRED


For any assistance with assembly or for missing parts please contact:





Place of purchase or Furniture Solutions on below

Customer Service (Australia) Phone-1300 794 188

Email- customerservice@furnitureolutions.com.au

PARTS LIST






A		2PCS	C		4PCS M6X20
B		4PCS M6X16	D		1PC 4mm

1.Seat Cushion

2.Backrest Cushion

3.Armrest Pads




ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until all bolts are in place



STEP 1

Attach Arm Supports A to the side panels using Bolt B and secure tightly with the Allen Key D provided. Attach Arm Pads to the arm supports using cup head Bolt C and securely tighten with Allen Key D.







STEP 2 - 2 PEOPLE REQUIRED

Locate Back Cushion connector pegs on the rear of the seat back. Fold up cover flap on bottom of Back Cushion and slide connector sleeves onto the connector pegs. Before pushing into locked position ensure pegs on both sides are located correctly on the pegs. Push down firmly on back cushion until connector sleeve has fully engaged connector pegs and is Back Cushion is secured onto pegs.



ASSEMBLY INSTRUCTIONS






ASSEMBLY IS COMPLETE




WARNING

- Do not allow children to play on the chair.
- Always leave the chair in an upright and closed position after use.
- Keep hands and feet clear of the mechanism.
- Only the occupant should operate the chair.




1




1. Press the button to raise the ottoman

2




2. Press the button to recline

3




3. Press the button to return to upright position

4




4. Press the button to stow the ottoman

5



5. Press the button to lift the chair

6



6. Press the button to get down to original position

FEATURE'S AND OPERATING OF RECLINER

Feature of Recliner:

Adjustment of head rest:

Internal Adjustable head rest for variable positions.

Please review diagrams below before operating headrest function.




To Adjust Headrest: Place both hands over shoulder as shown in diagram. Gently pull with both hands to desired position.



DO NOT PULL FROM SIDE: May cause damage to seams.



To return headrest back: push on both sides or use forearm to evenly move headrest back.



CAUTION

Always apply pressure to edge of Frame never in middle of headrest as may cause damage to filling.

CARE AND MAINTENANCE LEATHER

Varieties of materials are used in construction of “Recliner” furniture range, Such as Stainless Steel; Nickel plated steel; Chrome plated steel; Powder coated steel; Timber, Leather, PU synthetic fabric & a variety fabrics.

All will require some form of maintenance to extend the life of finishes and general appearance. Please see below instruction unique to your chosen model.

Leather Covering;

Keep dust free at all times.

Regular use a damp soft clean cloth and wipe down leather.

Pay special attention to areas where skin touches leather. IE : Armrest Pads, Headrest, front section of chair and footrest tops.

Please clean up spills immediately. Ensure to dry properly before use.

Periodic Leather Cleaning;

Every 3-4 months you need to give leather a good clean to remove excess body oils.

Please purchase a propriety leather cleaner and follow all directions indicated on packaging. You could also purchase a leather conditioner/protector to complement the leather after a good clean.

Frequency of periodic cleaning can vary due to colour of leather, use and environment.

A chair used 2 hours a day will require less cleaning than a chair used 8 hours a day.

Areas of high humidity will require more cleaning than areas of low humidity.

Professional Cleaning;

Even the most diligent house keeper cannot always prevent leather from aging or looking tired. We recommend you use the services of a reputable leather cleaning service when your cleaning does not appear to make a difference in appearance.

Things to know about leather;

The surface of leather can be affected by chemicals used in hair spray, gel, mousse, perfume, deodorants, some medications, alcohol and dye transference from clothing. Please factor this into your cleaning regime.

Care Instruction for FABRIC covering

Regular Care:

Vacuum regularly using low suction

Treat spills and stains as soon as possible

Spot Cleaning:

Use only upholstery detergents

Apply proprietary cleaning agent strictly to instructions provided with product

Do not wet filing

Do not rub excessively

Do not use Solvent based cleaners

Do not use dishwashing or laundry detergent

Dry in shade away from direct heat & sunlight

Allow to dry before re-use

Periodic Cleaning:

Clean with hot water extraction machine. Professional cleaning recommended

Do not wash , Do not dry clean , Do not shampoo

Do not remove cushion covers for separate cleaning even though they may have zippers

Warning:

Protect from direct sunlight

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

Care Instruction for chair & mechanism

Every 3-4 months lay chair over on its back and wipe and or vacuum action inside chair to remove excess dust and fluff, pay special attention to swivel action at base of chair, ensure all metal components are clean and free of impediments.

Ensure all bolts are firm refer to assembly instructions for location.

Important safety instructions:

Do not sit on arms

Do not stand on chair

Do not lean on back of chair

Do not drag chair always lift with the help of another person

Do not allow items to be entangled with mechanism IE: Blankets, pillows & clothing

Ensure swivel mechanism on chair base is clear of loose threads, long carpet fibre's or similar items

SAFETY WARNINGS AND ADVICE

Notices and Advice

Please be advised that products are limited in design for residential use only and are not suitable for commercial use.

Please be advised that materials used in your furniture are not impervious to neglect, acts of god, abuse, alcohol spills, improper use of chemicals such as bleach or any solvent based products.

Please be advised that heat sources such as direct sunlight, log fires, heaters and air conditioners can have adverse affects on your furniture.

Please be advised that fitting, bolts, nuts and or screws should be checked periodically to ensure they have not loosened over time. Remember do not overtighten.

Please be advised coverings are not animal proof. Claws can scratch covering & saliva is acidic and can damage finish of covering.

DO NOT

- Place in direct sunlight.
- Place in close proximity to open flame or heaters.
- Place in direct line of air conditioning ducting.
- Leave spills or food on sofa clean off immediately
- Pull loose thread, cut them instead.
- Sit or lean on arms
- Stand on chair

Safety warnings

- DO NOT:
 - drop, drag always with the help of another person lift and place, to avoid damage to floor surface & base of recliner chair.
 - Sit on arms or back when upright, this could damage internal mechanism.
 - Fold mechanism with linen or cushions on sofa.
 - Pull loose thread, cut them instead.
 - Jump, flop or stand on sofa.
 - Always release both glide handles before you attempt to move into upright position.
 - Ensure swivel mechanism on chair base is clear of loose threads, long carpet fibre's or simular items

WARRANTY DETAIL

2 Year Warranty

A two (2) year warranty applies to product against any defects associated with faulty workmanship for a period of (2) year from date of purchase.

Furniture Solutions accepts no responsibility for defects caused by incorrect assembly, mishandling, acts of god, general wear & tear including fading, creasing of covering, aging of foam and fibre filling IE Height reduce over time, stains from spills, chipping/scratching, exposure to extreme heat/cold, mould/mildew, hardware corrosion, misuse of the products & defects caused by failure in duty of care for the product in accordance with the care instructions. Warranty is based on normal household use and not for commercial use. Warranty only extends to original purchaser and is not transferable, except when given as a gift.

Notice:

While every effort is made to use quality materials our products are limited in design for domestic use only & are not suitable for commercial use.

Care should be taken not to place product near heat sources.

Duty of care:

While every attempt is made to supply product using quality components there is always a need from consumer to help ensure long life of use for product. Instruction manuals are designed with the nature of materials used in construction of the product.

*Proper use of item for only what it is designed to do

*Regular maintenance and cleaning

In areas of high content of salt air, pollution & moisture require more frequent cleaning.

Claim management:

To make a warranty claim, customers can either contact the retailer where the purchase was made or Furniture Solutions on contact details on page one. Proof of purchase will be required before proceeding with any claim. In the case of product defects providing photos may be able to speed up processing of the claim. If missing parts please refer to assembly instructions for identification of said part and contact either of the above.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.